

Kiddie Striker

Initial Assembly

1. Select a level area to operate game with plenty of room to allow for a line to form.
2. Fit the striker into the slot on the base.
3. Along the striker rail is a series of bolts; the nuts run along the back of the unit. Find the third nut from the bottom and remove it. Place the bracket on the bolt and replace the nut. (The bracket will be used for the brace.)
4. Assemble the brace to the back of the striker and base using the pins provided.
5. Take the large bolt and place the bell on it first. Then add the spacer and a flat washer. Insert the bolt into the top of the striker unit, add a flat washer to the back of the unit. Now add the nut to the back and tighten. **NOTE:** Make sure the bell does not touch the striker rail. If it does it will dull the sound. In this case, add more flat washers between the spacer and the unit as needed.

Kiddie Striker

Safety Rules

1. Be sure that there is plenty of clearance between the player and spectators.
2. Rope off lots of room to create a “striking zone”. Make sure that there is more than enough space to swing the mallet safely.
3. Never allow more than one person in the “striking zone” at a time.
4. Keep spectators clear from the sides and back of kiddie striker unit to prevent them from being struck by a deflected hit.
5. Regularly inspect mallet to insure that it is in sturdy condition.
6. Use only the mallet included with the game.
7. All players must wear shoes. (Children often miss the pad and strike their own foot.)
8. ***NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!***