




Setup & Operating Instructions

These Apply To Both Models 16212 & 17212

1. Open the rear door, and put the 75 balls inside. (Refer to Picture 1.)
2. Put the ball stopper on the blower tube and tighten the screw to hold in place. (Refer to Picture 2a. & 2b.)
(Balls are not included and sold separately)




3. Be sure the switches are in 'Off' position -- "O". The red switch is for the motor and the green switch is for the led light inside. Connect power cord to the electrical outlet, then turn on the motor and lights as needed. (Refer to Picture 3.)



4. If you would like to mix the balls without actually calling a game, cover the top of the blower tube while the motor is running. This will allow you to be able to mix up the balls quite well. (Refer to Picture 4.)



5. The ball mechanism blocks the ball from being drawn. To release the ball you slightly press on the button and the ball will pop up. After the ball is formally announced, you can put the selected ball in the correct position on the numbered tray. (Refer to Picture 5.)



6. At the end of each game, turn off the motor switch, lift the tray slowly and high enough, so that all the balls return to the ball chamber. Then lower the tray and you are ready for a new game. (Refer to Picture 6.)

