



Hayes Specialties Corporation

www.eHayes.com

1761 East Genesee Ave, Saginaw, MI 48601 USA

Local/Intl (989) 755-6541

Fax (989) 755-2341

Toll Free (800) 521-5219

e-mail: Info@eHayes.com

CONK THE CROW INSTRUCTIONS

PACKING LIST

| ITEM DESCRIPTION | QUANTITY |
|--|----------|
| Back Canvas 7'x7' | 1 |
| Front Canvas 42"x7' | 1 |
| "Four-Way" Fittings | 2 |
| "Elbow" Fittings | 4 |
| "Tee" Fittings | 2 |
| "Three-Way" Fittings | 2 |
| Lengths of Tubing 44.5" - A | 4 |
| Lengths of Tubing 41.5" - B | 6 |
| Lengths of Tubing 36" with rubber tips - C | 2 |
| Lengths of Tubing 24" - D | 4 |
| Right Hinge Assembly (has SMALLER diameter at one end of the tube) - E | 1 |
| Left Hinge Assembly - F | 1 |
| Stakes | 4 |
| Bean Bags | 12 |
| Crows with Hinges | 3 |
| Carrying Case | 1 |



SAFETY INSTRUCTIONS

1. Be sure that there is plenty of clearance between the player and spectators.
2. Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.
3. If using the game outdoors, it is strongly suggested that you use the stakes provided on either side of the bottom supports. Use sandbags on pavement. If there is a breeze, use sandbags with the stakes. (You must provide your own sandbags)
4. NEVER USE THE GAME IN STRONG WINDS OR LIGHTNING!!
5. Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down causing injury.
6. Use only the items provided with the game for use.

ASSEMBLY INSTRUCTIONS

1. Select a level area to operate the game with plenty of room to allow for a line to form.
2. Assemble the framework using the pictures and instructions provided. (Pictures are on the following page.)
3. Insert the (4) A Tubes into the (4) B Tubes, creating (4) 7' lengths.
4. Slide (2) "Tee" fittings onto 2 of these 7' lengths.
5. Use these (4) 7' lengths to create a square, using (2) "Elbow" fittings for the top corners, and (2) "Four-Way" fittings for the bottom corners. Note that the (2) "Tee" fittings go on the sides. These "Tee" fittings join the front frame to the back frame.
6. Place the C Tubes into the "Four-Way" fittings at the back of the game. These create the base. (Be sure to tighten down the fittings using the small bolts on them.)
7. Insert the D Tubes into the ends of both "Tee" fittings and at the ends of the "Four-Way" fittings on the bottom of the frame.
8. Place the remaining "Elbow" fittings on the ends of the bottom D Tubes, and insert (2) B Tubes into those "Tee" fittings vertically.
9. Slide the medium and small crows onto the E Tube. The medium crow goes to the left and small crow to the right. Slide the "Three-Way" fitting, and secure with clip. Slide the remaining crow onto the F Tube and insert the E Tube into the F Tube.
10. Attach the canvas to the framework using the Velcro straps. The bottom of the back canvas attaches to the front and side tubing, creating a well for the bean bags to fall into.
11. If you are using the game outdoors, it is strongly recommended that you use the stakes provided on either side either side of the bottom supports. Use sandbags on pavement. If it is breezy out, use sandbags on stakes as well. (You must provide your own sandbags.)

****IMPORTANT****

*Never fold up the canvas while it is wet. Allow it to dry thoroughly before storing.
Fold the canvas inward to help protect it and keep it clean.
All parts must be returned with game for deposit to be refunded.*

